





The Compact Headlamp is a reliable lighting solution that combines today's LED technology with a hands-free design for an excellent user experience. With the simple push button, users can activate LED technology that provides a great balance of brightness with hours and hours of runtime. Featuring an adjustable, comfortable head strap, the Compact Headlight adapts to a wide variety of user needs, from every day to work applications.

Lumens	Runtime	Beam Distance	Drop
 55 LUMENS	 8h	 30m	 1m



DESIGN BENEFITS
✓ Bright, compact and lightweight for a great hands-free user experience ✓ Easy-to-use push button ✓ Adjustable band that is removable and washable ✓ Durable construction with a shatterproof lens

PERFORMANCE BENEFITS
✓ Up to 12x brighter vs. standard LED technology ✓ Long runtime ✓ 2 modes: High and Low

LIGHT AND POWER SOURCE
✓ Features LED technology ✓ Operates on 2 AAA

BATTERY SPECIFICATIONS			
Battery Type	EVR SHD CZn		
Battery Size	AAA		
Number of Cells	2		
BATTERY PERFORMANCE			
Modes	Lumens (lm)	Runtime (h)	Beam Distance (m)
High	55	8	30
Low	15	24	---

PRODUCT SPECIFICATIONS	
Weight:	35 Grams / 1.23 Ounces
Dimensions:	89 mm x 37 mm x 28 mm 3.50" x 1.46" x 1.10"

ELECTRICAL CHARACTERISTICS	
Nominal Power Consumption:	0.6 W
Batteries:	3 AA Eveready 1212 3.0V dc
LED Specifications:	LED 3.0V cc /200 mA

BATTERY SPECIFICATIONS			
Battery Type	ENR Max Alkaline		
Battery Size	AAA		
Number of Cells	2		
BATTERY PERFORMANCE			
Modes	Lumens (lm)	Runtime (h)	Beam Distance (m)
High	55	17	35
Low	15	50	---

DISCLAIMERS
Tested according to ANSI FL1 Standards. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CERTIFICATES AND COMPLIANCE
EMC, EN62471, FCC
  

Modes
High, Low

OPERATING INSTRUCTIONS

1. Press 1 time for high.
2. Press 2 times for low.
3. Press again for off.

BATTERY CHANGING INSTRUCTIONS

1. Compress latch to open back battery door.
2. Follow instruction on light body for battery orientation.